

## Easy Fresh 2.0

The world's only air freshener dispenser where the cover is the air freshener

### Powerful enough to freshen larger areas


The cover contains 2-3 times more fragrance than gels or metered aerosols. The motor driven fan moves air freshener further than a typical passive system, so you'll freshen larger areas.

### Freshens consistently for 30 days

The smart chip controlled fan freshens consistently since it turns sparingly in week 1, and gradually turns more frequently until week 4 when it runs constantly.

### Easy to use

Maintenance is simple with easy to use LED and audible reminders along with a push button cover for quick removal and replacement.



Fan turns sparingly in week 1, and turns more frequently until week 4 when the fan runs constantly.


Smart Chip controls fan activation.

Audible Alert beeps every 3 1/2 minutes starting on day 33.

LED signals Green (ok) or Red (replace).

Push Tab makes it easy to remove the old cover.

Light Sensor detects when the room is not in use to conserve battery life.



### REFILLS 12/box

FRAGRANCE	W/BATTERY	W/O BATTERY
Herbal Mint	EF12HM	EF12NBHM
Honeysuckle	EF12HS	EF12NBHS
Kiwi Grapefruit	EF12KG	EF12NBKG
Fabulous	EF12FB	EF12NBFB
Spiced Apple	EF12SA	EF12NBSA
Ocean Mist	EF12OM	EF12NBOM
Cotton Blossom	EF12CB	EF12NBCB
Mango	EF12MG	EF12NBMG
Citrus	EF12CT	EF12NBCT
Cucumber Melon	EF12CM	EF12NBCM

### DISPENSER

EFCABPE Motorized Fan 12/cs

INTENSITY ↑